

## Optical Methods in Diagnosis

### Homework #6

We will determine photon absorption distribution for laser beams with finite diameters. Use the same parameters as Homework #5:  $\mu_a = 6 \text{ cm}^{-1}$ ,  $\mu_s = 414 \text{ cm}^{-1}$ ,  $g = 0.91$ , Henyey-Greenstein phase function,  $n_0(\text{outside medium})=1$ ,  $n_1(\text{tissue})=1.37$ ,  $\Delta r = \Delta z = 0.1 \text{ mm}$ .

Plot the fluence rate ( $\text{W}/\text{cm}^2$ ) distribution in the tissue (radius = 3 mm, thickness = 1.5 mm) for a collimated, normally incident beam that has (A) a uniform distribution with a radius of 0.5 mm and irradiance = 1  $\text{W}/\text{cm}^2$ , and (B) a Gaussian distribution with an  $e^{-2}$  radius of 0.5 mm and total power of 7.85 mW. Use variable-weight photons. Choose one of the following two approaches:


#### Method 1: Distribute input photons over area of the incident beam

Modify your code “ $x = y = z = 0$ ” to “ $z = 0$ ,  $x = \text{function}(r, n)$ ,  $y = \text{function}(r, n)$ ” for initial photon positions. *total power =  $1 \times \pi \times (0.05)^2 = 7.85 \text{ mW}$*


#### Method 2: Convolve the impulse response with the radial profile of the incident beam

After the completion of Monte Carlo simulations for the impulse response (initial position  $x = y = z = 0$ ), use a sub-program to compute the convolution of the impulse response and the source radial profile.


Note that the first photon-tissue interaction needs to be handled separately.



$$S(r) = \frac{2I_0}{\pi w^2} \cdot e^{-2r^2/w^2}$$




$$F(r) = 1 - e^{-2r^2/w^2}$$



shift-invariant system  
 → convolution integral to  
 simplify calculation.

(A) uniform distribution



probability of a photon's initial position  $r \leq r_1$

$$(r.n) = \int_{r=r_1} F(r) = \frac{\pi w_1^2}{\pi \cdot w^2} = \frac{r_1^2}{w^2} \quad r_1 = w \sqrt{(r.n)}$$

Fluence\_rate\_distribution, Incident beam power = 7.85e-3W, Source\_type = Gaussian

